

TECE Recovery Frame installation



Recovery Frame #9.240.643 or 9.240.645



The recovery frame can be used for two different installation scenarios.

1. The tile cut is not neat when recessing the glass push buttons into the wall, then the recovery frame will then cover the rough tile cuts.
2. When installing the TECESquare Metal push plates 9.240.810-811-812 and the recessed installation frame has not been installed.



Recessed installation frame

Important if you DO NOT have the 25mm minimum depth DO NOT cut the tiles. A traditional surface mount push button may then need to be used.

To install the Recovery frame the cut out must be 224 x 154mm if not then the tiles need to be cut to suit. Minimum wall depth 25mm for the push button to recess into.

To install

1. Remove the 4 screws from the recovery frame
2. The recovery frame is inserted into the hole and held into position by itself
3. Screw the black mounting frame from the push button into the white/grey dowels.
4. This will sandwich the recovery frame back to the tiled surface.
5. Adjust flush rods and clip push button onto the mounting frame.
6. Check actuation of the push buttons, ideally there should be slight movement of the button before it engages the mechanism.

